

24 Hour Analog Timer with 15 minute intervals

Instructions for Operation

- 1. To set present time: Turn the programming dial in the direction of the arrow until the triangular mark corresponds with the present time.
- To program: Ensure the arrow is on the present time. Push in the trippers situated around the dial to set equipment "ON" time. Each tripper represents 15 minutes.
- 3. For example: If you would like to set the time of activation from 11:00 AM to 1:30 PM, then push down the trippers situated between 11:00 AM and 1:30 PM, including the segments corresponding with 11:00 AM and 1:30 PM.
- 4. To activate equipment: Having selected your program, plug in your equipment to the timer and then plug the timer into a 120 Volt circuit. The timer will activate and de-activate the equipment as the dial rotates through the pushed down segments.
- 5. The selected program will remain the same each day unless modified by customer.
- 120 Volts/ 15 Amps/60 Hz/1800 Watts
- For Indoor Use Only
- 1 year warranty WARNING: DO NOT OVERLOAD