

ASSEMBLY INSTRUCTIONS

SUN HUT

THE BIG EASY™



2 PEOPLE
Recommended
for Assembly


SEE
ASSEMBLY
VIDEO



<http://youtu.be/qCy5H6-tpBE>

1 Identify and organize parts.

All models have similar parts to those shown below. Lay out all parts in groups, allowing plenty of space for assembly.



- A** Vent Cover(s)
- B** Tray Liner
- C** Corner Connectors
- D** End Clips
- E** Pole Connectors
- F** Pole Sections
- G** Tent Body




2 Start at the bottom.

Roll out tent body and bottom tray on floor. Assemble bottom pole sections and corner connectors inside the bottom tray.



4 Connect roof frame.

Insert pole sections between top corner connectors.* Make sure pole sections are inserted all the way into connectors.




7 Install liner and cover(s).

Fold out tray liner in bottom tray and smooth flat, making sure it reaches all corners. Secure vent cover(s) over vents if desired.



3 Assemble vertical poles.

Insert pole sections into bottom corner connectors. Use pole connectors as needed to build vertical pole sections (A & B). Place corner connectors at the very top of each vertical pole (C).*



5 Work tent body over frame.

Raise roof of tent body and gently work over top of frame. *NOTE: 2 people are required for 4x8 model assembly.*




8 Start growing!

Smooth out any remaining folds and wrinkles. Check all zippers to make sure they work smoothly. **START GROWING!**




6 Install extra supports.

Attach end clips to remaining pole sections. Install in roof as desired for your model, depending on where you plan to install support for lights, fans, etc.



4x8 model – Connectors with 4 holes go on both middle poles on 8' sides.




**Refer to Frame Diagrams on reverse for pole positioning on your particular model.*

For more information visit:
www.sun-huts.com


FRAME DIAGRAMS

Pole Lengths




NOTE: "Extra" pole sections are for additional roof support and for hanging hardware. Attach end clips and hang from frame (see Step #6 on reverse side).


M (2 x 4)
Part #706915



L (3 x 3)
Part #706920



XL (4 x 4)
Part #706925



XXL (4 x 8)
Part #706930

4-way
Corner
Connectors

